Instructions for use

WASHER - DRYER

GB

! This symbol reminds you to read this instruction manual.

GB

English, 1

WDF 740 P/G/A/K/X

Contents

Installation, 2-3-4-5
Unpacking and levelling
Connecting the electricity and water supplies
The first wash cycle
Technical data

Care and maintenance, 6
Cutting off the water or electricity supply
Cleaning the Washer-dryer
Cleaning the detergent dispenser drawer
Caring for the door and drum of your appliance
Cleaning the pump
Checking the water inlet hose

Precautions and tips, 7
General safety
Disposal

Description of the Washer-dryer and starting a wash cycle, 8-9
Control panel
Indicator lights
Starting a wash cycle

Wash cycles, 10
Table of wash cycles

Personalisation, 11
Setting the temperature
Setting the drying cycle
Functions

Detergents and laundry, 12
Detergent dispenser drawer
Preparing the laundry
Garments requiring special care
Load balancing system

Troubleshooting, 13-14

Product Guarantee and Repair Information, 15

Hotpoint

Connecting the drain hose

Connect the drain hose, without bending it, to a draining duct or a wall drain situated between 65 and 100 cm from the floor;

The drain hose may be connected to an under-sink trap. Before connecting the drain hose from the machine ensure that any blanks or removable ends have been taken off the spigot.

If it is placed over the edge of a basin or sink be sure the free end of the hose should not be under

GB

As the colours of the wires in the lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:
Connect Green & Yellow wire to terminal marked **E** or ⏚

Technical data	
Model	WDF 740 P/G/A/K/X
Dimensions	width 59.5 cm height 85 cm depth 53,5 cm
Capacity	from 1 to 7 kg for the wash programme from 1 to 5 kg for the drying programme
Electrical connections	please refer to the technical data plate fixed to the machine
Water connections	maximum pressure 1 MPa (10 bar) minimum pressure 0.05 MPa (0.5 bar) drum capacity 58 litres
Spin speed	up to 1400 rotations per minute
Energy rated programmes according to regulation EN 50229	Wash: programme 1; temperature 60°C; using a load of 7 kg. Drying: select the “Cottons” drying programme and set the drying level to “

Indicator lights

The indicator lights provide important information.
This is what they can tell you:

Wash cycle phase indicator lights
As the WASH CYCLE knob is rotated, the indicator lights illuminate, indicating the stages which will be performed by the machine in accordance with the selected wash cycle.

Once the desired wash cycle has been selected and has begun, the indicator lights switch on one by one to indicate which phase of the cycle is currently in progress.

Note: during the “Drain” phase, the indicator light corresponding to the “Spin” cycle phase will illuminate.

Function buttons and corresponding indicator lights
When a function is selected, the corresponding indicator light will illuminate.
If the selected function is not compatible with the programmed wash cycle, the corresponding indicator light will flash, a sound signal will be emitted and the function will not be activated.
If a function which is incompatible with another function selected previously, only the most recent selection will remain active.

Temperature indicator light
When a temperature value is selected, the corresponding indicator light will illuminate.

Drying indicator light
When a drying value is selected, the corresponding indicator light will illuminate.

Child lock indicator light
To activate the control panel lock, press and hold the button for approximately 2 seconds. When the indicator light is illuminated, the control panel is locked. This means it is possible to prevent wash cycles from being modified accidentally, especially where there are children in the home.
To deactivate the control panel lock, press and hold the button for approximately 2 seconds.

Door locked indicator light
If this indicator light is on, the appliance door is locked to prevent it from being opened accidentally; to avoid any damage, wait for the indicator light to switch off before you open the appliance door q2lSn0(ooooo94)30(e)30( )30(a)30(p2l ⁄Lang

Wash cycles

GB

Table of wash cycles

Cycle	Max. temp. (°C)	Max. speed (rpm)	Description of the wash cycle
Cotton	60	1000	Normally soiled whites and delicate colours.
Cotton (2)	60	1000	Lightly soiled whites and delicate colours.
Cotton Eco	60	1000	Normally soiled whites and delicate colours.
Cotton Eco (2)	60	1000	Lightly soiled whites and delicate colours.
Synthetics	60	1000	Normally soiled whites and delicate colours.
Synthetics (2)	60	1000	Lightly soiled whites and delicate colours.
Wool	40	800	Delicate fabrics.
Wool (2)	40	800	Delicate fabrics.
Delicates	40	800	Delicate fabrics.
Delicates (2)	40	800	Delicate fabrics.
Dark	40	1000	Dark coloured fabrics.
Dark (2)	40	1000	Dark coloured fabrics.
Mix	40	1000	Mixed fabrics.
Mix (2)	40	1000	Mixed fabrics.
Rinse	-	1000	Rinse cycle.
Spin	-	1000	Spin cycle.
Drain	-	-	Drain cycle.
Steam Care	40	1000	Steam cycle to reduce creases in clothes.
Refresh	40	1000	Steam cycle to refresh clothes.
Hygiene	60	1000	Steam cycle to sanitise clothes.
Easy Iron	40	1000	Steam cycle to reduce creases in clothes.
Jeans	40	1000	Jeans and dark coloured fabrics.
Sportswear	40	1000	Sportswear and technical fabrics.
Outdoor	40	1000	Outdoor clothing and technical fabrics.
Down Duvet	40	1000	Down duvets and down clothing.
Duvet	40	1000	Duvets and bedding.
Towels	60	1000	Towels and bathrobes.
Baby Care	60	1000	Baby clothes and soft fabrics.
Sanitise	60	1000	Sanitising cycle for whites.
Rinse & Spin	-	1000	Rinse and spin cycle.
Quick Wash	40	1000	This cycle was designed to wash and dry lightly soiled small loads quickly. By selecting this cycle it is possible to wash and dry a maximum load of 1 kg in just 60 minutes.
Ready to Wear (*)	40	1000	Normally soiled whites and delicate colours.

(*) Ready to Wear Detergents

! Please note, this is an automatically programmed wash and dry cycle, therefore it is not possible to manually set a drying time or drying level in conjunction with this cycle.

! Please note, the Drying indicator illuminates only during the drying phase of the cycle, not when the cycle is first selected.

Drying Max. Mixed Wash cycles

Setting the temperature

By pressing the TEMPERATURE button to set the wash temperature (see Table of wash cycles).
The temperature may be lowered, or even set to a cold wash (

Troubleshooting

Hotpoint

GB

Your Washer-dryer could fail to work. Before contacting the Technical Assistance Centre (see “Assistance”), make sure that the problem cannot be solved easily using the following list.

Problem:	Possible causes / Solutions:
The machine does not switch on.	
The wash cycle does not start.	
The machine does not dry.	
The clothes are too hot when the drying cycle is finished.	the clothes appear too hot to handle leave the door open to allow to cool further before removing from the machine.
The machine does not fill with water or the indicator light for the first wash cycle stage flashes rapidly.	
The machine continuously fills with water and continually drains away or Water left in the drum or Stuck on wash.	
The machine does not drain or spin - ‘START/PAUSE’ flashing orange.	
The wash programme takes too long.	
The Display sticks at one ‘time to end’ for more than 1 Minute or the Display changes the estimated ‘Time to End’ during the programme.	
The machine vibrates a lot during the spin cycle.	

The machine is noisy.

The machine wont spin properly.

The machine leaks from the dispenser.

GB

Indesit Company Spa
Viale Aristide Merloni, 47
60044 Fabriano (AN)
Italy
www.hotpoint.co.uk